


# Water Filling Station Instructions



***(PLEASE ENSURE A COPY REMAINS IN TRUCK AT ALL TIMES)***

- **Access to site.** Take care when approaching and entering the water filling station site. Pay particular attention to pedestrians and other motorists. Obey traffic rules.
- **Parking.** Position truck to allow safe and efficient access. Take care when stationary on the road side including entering and exiting the vehicle. Wear a hi-vis vest.
- **Pedestrian Safety.** Minimise obstruction of the footpath and take all safety precautions including the positioning of safety cones to prevent the risk of tripping hazards or injury to pedestrians.
- **Overhead Filling.** Drive under flexible hose until it enters the tank. (P.T.O. For Visual)

Maximum truck/tanker filling inlet height	3.9m
Minimum tanker filling inlet height	2.4m
Minimum tank inlet	200mm diameter

**(For safety do not climb onto tanker)**

- **Culcairn Cabinet Door.** Use the small steel key No. 1333 provided to unlock the top section of the water filling station.
- **Jindera, Burrumbuttock, Brocklesby and Gerogery Cabinet Doors.** Use the large steel key No. 5295 FS provided to unlock padlock on filling station door.
- **Water Flow.** Follow the operating instructions displayed on the screen interface. (As shown below)
  1. Allow the "scan iButton" screen to appear.
  2. Touch iButton on reader for 3 seconds.
  3. Press green Start button to start flow.
  4. Water will start to dispense.
  5. Press red Stop button to stop flow and finish transaction.  
***(Shut down of water supply can take up to 10 seconds)***
  6. The litres dispensed will be displayed on the screen.
  7. Please **close and lock door with key.**
- **Exit.** Take care exiting the water filling station site. Pay particular attention to pedestrians and other motorists.

**FOR SERVICE DIFFICULTIES AND FAULTS – PLEASE CALL (02) 6036 0100**

**TO REPORT DAMAGE OR VANDALISM – PLEASE CALL (02) 6036 0100**